

Linear actuator CAMT




Play-free motion



Easy installation



Compact design



Standards

IEC/UL 60601-1 (Edition 3.1)

IEC/UL 60601-1-2 (Edition 4)



**New medical
solution**

CAMT


Linear actuator for surgical tables and procedure chairs

Benefits

- Play free motion
- Easy installation
- Compact design

Standards

- IEC/UL 60601-1 (Edition 3.1)
- IEC/UL 60601-1-2 (Edition 4)



Technical data

	Unit	CAMT20
Rated push load	N	6 000
Rated pull load	N	6 000
Static load (push/pull) ¹⁾	N	13 200
Safety factor on rated load ^{2) 3)}	–	4
Speed (full load to no load) ⁴⁾	mm/s	5 to 6,5
Stroke	mm	50 to 250
Voltage	VDC	24
Current consumption	A	10
Duty cycle	%	10 (1/9 minutes)
Ambient temperature	°C	+10 to +40
Degree of protection	–	IP20
Noise level (max)	dB	≤ 55
Weight ⁵⁾	Kg	5,8

¹⁾ Compliant with static load according to IEC/UL 60601-2-46

²⁾ Static safety factor to prevent mechanical hazards according to IEC/UL 60601-1

³⁾ Depending on stroke and attachment type, safe work load in push direction is reduced. For details, see diagram **Safety factor load conditions**

⁴⁾ Speed with 24 V DC, speed with V/SCU is higher. For details, see diagram **Load-Speed**

⁵⁾ For stroke 250 mm, without attachment

Product benefits

Play free motion – Extra comfort

Feel the smooth movement introduced by CAMT because all parts are play-free. Unlike common actuators which shake when the load direction changes, CAMT keeps the movement smooth throughout the whole process (↳ diagram 1).

Easy installation – Simplicity

It is easy to install thanks to the new design with extra front and rear attachment with 1 or 2 DOF in motion (↳ fig. 1 and 2).

Compact design – Perfect system integration

The compact design enables a perfect system integration. It can be installed as a single actuator or be combined with other CAMT actuators and a column (e.g. CPMT) to achieve combined motion in any direction (↳ fig. 3).

Fig. 1

Front attachment: play-free



Fig. 2

Rear attachment: play-free





Diagram 1


Displacement [mm]



CAMT actuator — Standard actuator —

Fig. 3


Surgical module



¹⁾ Actuator after service life of 10 years in a typical medical procedure equipment application, with the meaning of 60 000 cycles at average load of 3 000 N and average stroke of 100 mm.

Dimensional drawing

Clevis attachment (CAMT20-xxxxx-00L-AA-AFx-000)




Retracted length:

$L = \text{Stroke (S)} + \text{Offset (X)} + 104$

* Standard Offset = 36

1 DOF attachment (CAMT20-xxxxx-00x-BB-AFx-000)



Retracted length:


$L = \text{Stroke (S)} + \text{Offset (X)} + 50$ (long protection tube)

$L = \text{Offset (X)} + 150$ (short protection tube)

* Standard Offset = 30

Long protection tube Short protection tube


2 DOF attachment (CAMT20-xxxxx-00x-CC-AFx-000)



Retracted length:
 L = Stroke (S) + Offset (X) + 50 (long protection tube)
 L = Offset (X) + 150 (short protection tube)

* Standard Offset = 60


Rod with D8 JS7 bore (CAMT20-xxxxx-00x-DF-AFx-000)



Retracted length:
 L = Stroke (S) + Offset (X) + 68 (long protection tube)
 L = Offset (X) + 168 (short protection tube)

* Standard Offset = 30


Motion angles of play front and rear attachments



Performance diagrams


Speed-load diagram

Speed [mm/s]



Current-load diagram


Current consumption [A]



Safety factor load conditions


Push load reduction for static safety factor S=4 (IEC/UL 60601-1)

Load [N]



Safe push and pull load for static safety factor S=2.2 (IEC/UL 60601-2-46)

Load [N]




— Clevis attachment
 — 1 DOF attachment, with long protection tube ^{1) 2)}

— 2 DOF attachment, with long protection tube ¹⁾
 — Valid for all CAMT configurations


¹⁾ No load reduction with short protection tube

²⁾ No load reduction for 1DOF U-bracket

Rear attachment orientation



Standard bracket (1 DOF and 2 DOF)




U-bracket (1 DOF)

Suitable control units and accessories


	Control units							
	SCU 1	SCU 5	SCU 9	VCU 5	VCU 8	VCU 9	*BCU 5	*BCU 8
CAMT	•	•	•	•	•	•	•	•
Operating switches								
EHA 3	•	•	•	•	•	•	•	•
STJ	•	•	•	•	•	•	•	•
STE	•	•	•	•	•	•	•	•
Hand switch	Foot switch							Desk switch

Connecting diagram



Encoder resolution 0,02127 mm/edge

Electrical connection



Plug P1: DIN-8 connector

Flying leads

Plug P2: Molex Mini-fit Jr. 6-pole

Plug P1	Wire color	Section	Function	Plug P2
1+7	Blue	AWG 16	- on, + off	4
2+4	Red	AWG 16	+ on, - off	1
3	Pink	AWG 24	+ 5 V	2
5	Grey	AWG 24	gnd	5
6	Yellow	AWG 24	hall sensor 1 signal	3
8	Green	AWG 24	hall sensor 2 signal	6

Ordering key

		<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="padding: 2px;">C</td> <td style="padding: 2px;">A</td> <td style="padding: 2px;">M</td> <td style="padding: 2px;">T</td> <td style="padding: 2px;">2</td> <td style="padding: 2px;">0</td> </tr> </table>	C	A	M	T	2	0	-	<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> </tr> </table>					-	<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> </tr> </table>				-	<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> </tr> </table>				-	<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> </tr> </table>					-	<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> <td style="width: 20px; height: 20px;"></td> </tr> </table>				
C	A	M	T	2	0																															

Type	
Load	
2	6 000 N
Voltage	
0	24 VDC
Stroke length	
0 5 0	50 mm
1 0 0	100 mm
1 5 0	150 mm
2 0 0	200 mm
2 5 0	250 mm
x x x	Customised (10 mm steps)
Distance between front pivot and gear box (Offset "X", see dimensional drawing)	
0 0	Standard
x x	Customised (10 mm steps)
Protection tube length (LP, see dimensional drawing)	
0 0 S	Short (shortest possible length)
0 0 L	Long (lead screw covered when retracted)
x x x	Customised (10 mm steps)
Front attachment	
A	Rod clevis D12 H7 bore
B	1 DOF attachment
C	2 DOF attachment
D	Rod with D8 JS7 bore
Rear attachment	
A	Rear clevis D20 H7 bore 0° (only with long protection tube)
B	1 DOF attachment 0°
C	2 DOF attachment 0°
D	Rear clevis D20 H7 90° (only with long protection tube)
E	1 DOF attachment 180°
F	1 DOF U-bracket attachment 0°
G	1 DOF U-bracket attachment 90°
H	1 DOF U-bracket attachment 180°
I	2 DOF attachment 180°
Mechanical options	
A	Backup nut
Electrical options	
F	End limit switches
Cable options	
A	1 m straight with DIN8 plug
B	2,3 m straight with DIN8 plug
C	2,3 m straight with flying leads
0	Without cable

■ Options shown in red are only available on request. Contact Ewellix for more information on minimum quantities and additional costs.



ewellix.com

© Ewellix

All contents of this publication are the property of Ewellix, and may not be reproduced or given to third parties (even extracts) without permission. Although great care has been taken in the production of this catalog, Ewellix does not take any responsibility for damage or other loss resulting from omissions or typographical errors. The photo may differ slightly in appearance from the actual product. Due to continuous improvements being made in our products, the product's appearance and specifications are subject to change without notice.

PUB NUM IL-07014/4-EN-January 2025

Schaeffler and the Schaeffler logo are trademarks of the Schaeffler Group.